



9	621002	1	14+ Ford Transit Van Installation Sheet
8	102010	20	Floor Spacer - 3/8" Thick 4" x 6"
7	648011	1	Push-In Rubber Plug for Panel - 2" Hole x 1/8" Sheet (50mm)
6	642513	30	#10 - 1-1/4" SS Phillips Flat Head Self Drilling Screw
5	642511	95	#10 - 3/4" SS Phillips Flat Head UnderCut Self Drilling Screw
4	109013	1	14+ Ford Transit Van Step
3	101182	1	14+ Ford Transit - 130" WB - Rear Panel 3 - .100
2	101181	1	14+ Ford Transit - 130" WB - Center Panel 2 - .100
1	101180	1	14+ Ford Transit - 130" WB - Front Panel 1
#	PART NO.	QTY.	DESCRIPTION

Rev. Weight
-- 79.21 Lbs.


7541 Chapman Ave Unit B
Garden Grove, Ca 92841

Description		14+ Ford Transit - 130WB Std - w/Step	
Material	Look To Item	Item No.	100053
<small>PROPRIETARY AND CONFIDENTIAL</small> <small>THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF J&M TRUCK BODIES, ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF J&M TRUCK BODIES IS PROHIBITED.</small>		SIZE	Date
		A	10/17/2019
		Drawn By.	J. Chauvin
		SCALE:	1:15

5

4

3

2

1