



9	631002		14+ Ford Transit Van Installation Sheet
8	102010	20	Floor Spacer - 3/8" Thick 4" x 6"
7	648011	1	Push-In Rubber Plug for Panel - 2" Hole x 1/8" Sheet (50mm)
6	642513	20	#10 - 1-1/4" Stainless Flat Head Self Drill Screw
5	642511	95	#10 - 3/4" Stainless Flat Head Self Drill Screw
4	109013	1	14+ Ford Transit Van Step
3	101179	1	14+ Ford Transit Van - 148" WB Std - Rear Panel 3
2	101178	1	14+ Ford Transit Van - 148" WB Std - Center Panel 2
1	101177	1	14+ Ford Transit Van - 148" WB Std - Front Panel 1
#	PART NO.	QTY.	DESCRIPTION

Rev. Weight  
-- 91.02 Lbs.



7541 Chapman Ave Unit B  
Garden Grove, Ca 92841

Description		14+ Ford Transit Van - 148" WB Std. - w/Step	
Material	Look to Item	Item No.	100054
<small>THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF J&amp;M TRUCK BODIES, ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF J&amp;M TRUCK BODIES IS PROHIBITED.</small>		SIZE	Date
		<b>A</b>	9/26/2020
		Drawn By.	J. Chauvin
		SCALE:	1:15

5

4

3

2

1