



10	631002	1	14+ Ford Transit Van Installation Sheet
9	102010	20	Floor Spacer - 3/8" Thick 4" x 6"
8	648011	1	Push-In Rubber Plug for Panel - 2" Hole x 1/8" Sheet (50mm)
7	642513	30	#10 - 1-1/4" SS Phillips Flat Head Self Drilling Screw
6	642511	120	#10 - 3/4" SS Phillips Flat Head UnderCut Self Drilling Screw
5	109013	1	14+ Ford Transit Van Step
4	101176	1	14+ Ford Transit - 148" WB Ext. - Rear Panel 4
3	101175	1	14+ Ford Transit - 148" WB Ext. - Center Panel 3
2	101174	1	14+ Ford Transit - 148" WB Ext. - Center Panel 2
1	101173	1	14+ Ford Transit - 148" WB Ext. - Front Panel 1
#	PART NO.	QTY.	DESCRIPTION

5

4

3

2

1

Rev.	Weight
--	109.86 Lbs.



7541 Chapman Ave Unit B  
Garden Grove, Ca 92841

Description	14+ Ford Transit - 148WB Ext - 2500 - Single Wheel - w/Step
-------------	--

Material	Item No.
Look To Item	100055

PROPRIETARY AND CONFIDENTIAL	SIZE	Date
THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF J&M TRUCK BODIES. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF J&M TRUCK BODIES IS PROHIBITED.	A	10/17/2019

Drawn By.	J. Chauvin
SCALE:	1:18