



NOTE: Driver step is a mirror of passenger step

11	631002	1	14+ Ford Transit Van Installation Sheet
10	102010	20	Floor Spacer - 3/8" Thick 4" x 6"
9	648011	1	Push-In Rubber Plug for Panel - 2" Hole x 1/8" Sheet (50mm)
8	642513	30	#10 - 1-1/4" SS Phillips Flat Head Self Drilling Screw
7	642511	125	#10 - 3/4" Phillips Flat Head Self Drilling Screw - SS
6	109013-01	1	14+ Ford Transit Van Step - Driver Side - ATB
5	109013	1	14+ Ford Transit Van Step
4	101176	1	14+ Ford Transit - 148" WB Ext. - Rear Panel 4
3	101187	1	14+ Ford Transit - 148" WB Ext. - Duel Wheel - Center Panel 3
2	101186	1	14+ Ford Transit - 148" WB Ext. - Duel Wheel - Center Panel 2
1	101173-01	1	14+ Ford Transit - 148WB Ext Double Sliding Door - Front Panel 1 - ATB
#	PART NO.	QTY.	DESCRIPTION

5

4

3

2

1

Rev. Weight
-- 112.42 Lbs.


7541 Chapman Ave Unit B
Garden Grove, Ca 92841

Description 14+ Ford Transit - 148WB Ext 3500 - Double Sliding Door - w/Step - ATB

Material .100 Alum. Treadbrite Item No. 100056-01

PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF J&M TRUCK BODIES. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF J&M TRUCK BODIES IS PROHIBITED.

SIZE Date 10/17/2019
A Drawn By. J. Chauvin
SCALE: 1:18