



Note: Install with 642511 Screws unless Longer is needed.

8	648011	1	Push-In Rubber Plug for Panel - 2" Hole x 1/8" Sheet
7	642513	15	#10 - 1-1/4" SS Phillips Flat Head Self Drilling Screw
6	642511	65	#10 - 3/4" SS Phillips Flat Head UnderCut Self Drilling Screw
5	647082	4	Zinc-plated Steel Unthreaded Spacer 3/4"OD x 1/2"L
4	109015	1	14+ Ford Transit Connect Step Asm. - Driver
3	109014	1	14+ Ford Transit Connect Step Asm. - Passenger
2	101195	1	14+ Ford Transit Connect 121WB - Rear Panel
1	101193	1	14+ Ford Transit Connect - Front Panel
#	PART NO.	QTY.	DESCRIPTION

Rev. Weight  
-- Lbs.

**JM**

7541 Chapman Ave Unit B  
Garden Grove, Ca 92841

Description		14+ Ford Transit Connect 121WB Flooring - ATB	
Material	.100 Alum. Treadbrite	Item No.	100068
<b>PROPRIETARY AND CONFIDENTIAL</b>		SIZE	Date
THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF J&M TRUCK BODIES. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF J&M TRUCK BODIES IS PROHIBITED.		<b>A</b>	10/31/2018
		Drawn By.	J. Horvath
		SCALE:	1:12

5

4

3

2

1