



**INSTRUCTIONS:**

1. Install front mounting bracket using the factory screws
2. Install rear mounting bracket using provided #10 screws
3. Bolt cab organizer to mounting brackets using 1/4-20 screws

NOTE: No drilling required. Use the factory holes in the seat boxes.

7	N/A	2	Key (Make Sure Keys Fit The Lock)
6	642026	2	10-24 Flanged Nyloc Nut
5	642031	2	10-24 x 5/8" Pan Head Screw
4	642062	4	1/4-20 x 5/8" Pan Head Screw
3	041066	1	14+ Ford Transit Cab Organizer - Rear Mounting Brkt
2	041065	1	14+ Ford Transit Cab Organizer - Front Mounting Brkt (Without Hand Brake)
1	049008	1	14+ Ford Transit Cab Organizer - Asm. (Without Hand Brake)
#	PART NO.	QTY.	DESCRIPTION

Rev. Weight  
-- 17.50 Lbs.

  
7541 Chapman Ave Unit B  
Garden Grove, Ca 92841

Description	14+ Ford Transit Cab Organizer (2021 Newer or without Hand Brake)		
Material	.080 Aluminum	Item No.	040008
<small>PROPRIETARY AND CONFIDENTIAL</small> <small>THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF J&amp;M TRUCK BODIES. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF J&amp;M TRUCK BODIES IS PROHIBITED.</small>		SIZE	Date
		<b>A</b>	5/2/2022
		Drawn By.	S.Gutierrez
		SCALE:	1:6

5

4

3

2

1